

Ensuring that the AQUAvalve5 floods and drains correctly

- 1** Making sure your AQUAvalve5 floods and drains correctly is simply achieved and only takes a few seconds.
- 2** Hold the AQUAvalve5 at eye level so that you can see the silicone fitted to the top float resting on the hole below it.
- 3** The silicone must create a tight seal when touching the hole.
- 4** If it looks like it is not sitting parallel on the hole below, simply lift the top float and apply pressure to one side of the silicone, drop the float and hold at eye level again. Repeat the procedure if necessary.

Care and maintenance

- 1** At the end of your growing season, clean the AQUAvalve5 using warm soapy water. Using an old tooth brush will help.

The AQUAvalve5 is easily disassembled. The top float will slide all the way across and the bottom float is unclipped from its pivoting position. The circular discs fitted to the top float can also be removed by using pliers to grip the raised point.


At this point it is advisable to remove the silicones to avoid them being lost.

- 2** It is also handy to have a paper clip or pipe cleaner to hand so that you can push it through the AQUAvalve5 nozzle, this will remove any lime scale build up that may have occurred during the growing season.

Blowing through the AQUAvalve5 nozzle will also help to remove any build up. Do not under any circumstances use a drill & drill bit to clear the AQUAvalve5 nozzle.

This will potentially damage the AQUAvalve5 beyond repair.


Your 4Pot XL system set-up guidelines



Layout 1



Layout 2




4Pot XL system contents

- 1x 12.4 gallon reservoir & lid
- 1x 3/8" top hat grommet
- 1x 3/8" golf filter
- 2x 3/8" inline tap
- 2x 3/8" cross connector
- 4x 3/8" tee connector
- 4x 6.6 gallon pot
- 4x 1Pot XL tray & lid
- 4x AQUAvalve5
- 13ft of 3/8" pipe
- 4x PotSock Round


Plan views and options

Suggested layout

Layout 1




Layout 2



Advice

- Pot up your plants, water through, then allow your plants to establish in the pots for a period of 7 to 10 days before turning your system on. This will encourage a stronger and healthier root system.
- Always raise your reservoir/FlexiTank to a minimum of 6" above the highest AQUAvalve5 and re-fill the reservoir/FlexiTank when there is approx. a 1/3 of the solution left – NEVER ALLOW THE RESERVOIR/FLEXITANK TO RUN EMPTY.
- With AQUAvalve5 systems mineral or organic fertilisers may be fed via the reservoir and pipework. Organic fertilisers will require a water pump in the reservoir running for 15 mins every 2 hrs and cleaning of the reservoir, pump, and filter each time the reservoir empties. Flush pipework with plain water every time the reservoir empties.
- Clean all substrate from the bottom and sides of the pots before placing in each tray. This will ensure your system is clean from the start.
- Always use free draining substrates, for example: soil/perlite, coco/perlite, soil/clay pebbles, coco/clay pebbles, rockwool/clay pebbles.

1Pot XL dimensions




1Pot XL setup instructions




Fit the PotSock Round over the base of your pot(s)



Fill pot with medium and pot up plants.
Water through pot and allow to drain outside the tray



Remove collar
Push 3/8" pipe through collar and attach to AQUAvalve5 nozzle
Rescrew collar - **DON'T overturn...** when you feel it grip **STOP**



Connect AQUAvalve5 so 'half moon' is on T section in the tray



Position tray so it is level



Cut 3/8" / 1/2" pipe to appropriate length



Push 3/8" top hat grommet into reservoir, then push 3/8" pipe through grommet



Inside the reservoir push 3/8" filter into 3/8" pipe



Place pot in the tray, make sure it is **CLEAN!**
Place lid over valve onto tray

Using your front instruction sheet, repeat the module set up instructions for the number of trays.

Allow your plants to establish for 7-10 days before turning system on

Advice

If you require any guidance email - info@autopot-usa.com